

WHITE SHUTTERS

1: MEASURING



Frame:

Measure in front of where the frame will fit



Measuring:

Measure the main width in 3 places and use the **smallest size**.
Measure the main height in 3 places and use the **smallest size**.



Rails:

Measure from the window sill up to the **centre** of where you want you want your rail



Tier splits:

Measure from the window sill up to the **centre** of where you want your split



Tposts:

Measure from the left to the **centre** of each Tpost.



Square:


Measure across the diagonal to check the squareness.



Level:

Check the level of the window sill, each side and top of the window

2: SIZE DEDUCTIONS



3: RAIL & TPOST DEDUCTIONS

Rail heights:


Deduct the shadow gap or fitting clearance from your rail height

Tier heights:


Deduct the shadow gap or fitting clearance from your tier split

Tpost widths:

Deduct the shadow gap or fitting clearance from each Tpost measurement



4: TPOST DEDUCTIONS



5: TIER HEIGHT DEDUCTIONS

(Side view - Measuring from the bottom)

Tier on Tier Height Deductions

- Deduct the shadow gap from your tier height
- Example: Deduct 5mm if you have allowed a 10mm shadow gap
- Measurements are required from the window sill to the centre of the Tpost
- If you want the top of the Tpost level with a feature on your window, deduct a further 30mm

Note:

The order height is from the bottom of the frame to the centre of the Tpost (Point A)

If you want the top of the Tpost to line up with a feature on your window, measure to point B and deduct 30mm.

The sizes you enter should be to the centre of the Tpost.

